

ROLLEI INFRARED

Wywoływacz	Rozcieńczenie	Naświetlanie	35mm	120	Błony	Temp.
Diafine		400	3+3			22°C
HC-110	B	400		8.5		20°C
HC-110	B	400		8.5		20°C
Ifosol S	1+9	400		7.25		20°C
PMK	2+4+100	6-8	7.5	7.5		21°C
PMK	1+2+100	12		12		24°C

ROLLEI R3

Wywoływacz	Rozcieńczenie	Naświetlanie	35mm	120	Błony	Temp.
D-76		100		7		20°C
D-76		200	10			20°C
D-76		400	14			20°C
HC-110	B	400	14			20°C
HC-110	B	640		16		20°C
ID-11		100		7		20°C
ID-11		200	10			20°C
ID-11		400	14			20°C
Microphen		100	9.5			20°C
Microphen	1+1	400	13-14			24°C
Microphen	1+1	400	13-14			24°C
Perceptol		200	14			20°C
Promicrol	1+14	400	14			20°C
Promicrol	1+14	400	10			24°C
Promicrol	1+9	400	10			20°C
Promicrol	1+9	400	6.5			24°C
Promicrol	1+9	1600	9.5			24°C
Promicrol	1+9	1600	14			20°C
Promicrol	1+14	1600	15			24°C
Promicrol	1+14	1600	21			20°C
Rollei R3 High Speed	1+7	100	13			20°C

Rollei R3 High Speed	1+7	200	14			20°C
Rollei R3 High Speed	1+7	400	14			20°C
Rollei R3 High Speed	1+7	800	18			20°C
Rollei R3 High Speed	1+7	1600	22			20°C
Rollei R3 High Speed	1+7	3200	26			20°C
Rollei R3 High Speed	1+7	6400	32			20°C
Rollei R3 Low Speed	1+4	25	22			24°C
Rollei R3 Low Speed	1+4	50	23			24°C
Rollei R3 Low Speed	1+4	100	24			24°C
Rollei R3 Low Speed	1+4	200	25			24°C
Xtol	1+2	200-400	24-29			20°C

ROLLEI RETRO

Wywoływacz	Rozcieńczenie	Naświetlanie	35mm	120	Błony	Temp.
D-76		400	14			20°C
D-76	1+3	400	28			20°C
ID-11		400	14			20°C
ID-11	1+3	400	28			20°C