

RODINAL

One-shot developer

for black and white films

Einmal-Entwickler

für Schwarzweiß-Filme

Révélateur à bain perdu

pour films noir et blanc

125 ml
500 ml

Instructions for use

English

RODINAL is characterised by very good contour sharpness and high emulsion speed yield. The subject contrast can be influenced by varying the dilution of the concentrate.

Mixing: 1 part concentrate to 25 or 50 parts water at a temperature of 20° C.

Shelf life: The concentrate remains usable for at least 6 months once the bottle has been opened if the screw top is tightly closed. When diluted for use, **RODINAL** only keeps for a short time and therefore should only be mixed immediately before use.

Developing times at 20° C – Dilution 1 + 25 or 1 + 50

(Small tank processing)

Agitation: Small tanks – continuously for the first minute, and then tilt every 30 seconds.

The film development times listed below are guidelines. Through variations in processing the result can be influenced according to requirements. (see diagram 1)

Temperature variations:

Development times (small tank) at temperatures other than 20° C are indicated in the time/temperature diagrams. (see diagram 2)

NOTE

To permit the trouble-free recycling of plastic bottles and canisters, usually the leftover chemicals have to be removed beforehand.

To do this, we recommend rinsing them out with water.

So that this rinsing water does not pollute the effluents, part of the mixing water needed should be used for rinsing, and then added to the solution.

Additional safety recommendations

Developers may irritate the skin and cause allergic skin reactions. Avoid contact with skin and eyes; wear protective gloves and protective goggles if necessary. If photographic chemicals get onto the skin or into the eyes, rinse away with water. Ventilate room well. Keep inaccessible to children. If swallowed rinse mouth with plenty of water. Seek medical advice.

RODINAL contains potassium hydroxide and aminophenol

Note the hazard information on the individual packs.

«In case of complaint, please quote serial number and send proof if possible».